LIVE TO PLAY LIVE®

JIMDUNLOP.COM

9250300047800 rev B

MXR Phase 90

CUSTOM SCRIPT PHASE

Operation Manual

CSP101SL SCRIPT PHASE 90

DESCRIPTION

- Hand-wired circuit board built with original spec 1975 components
- Original high quality Switchcraft jacks and Carling bypass switch
- Hand-selected FETs matched to produce and rich phasing

POWER

The MXR Script Phase 90 can be powered by one 9-volt battery (accessed through the bottom of the pedal).

CONTROLS

- SPEED knob controls rate of phase effect
- FOOTSWITCH toggles effect on/bypass (indicated by red LED)

DIRECTIONS

- Run a cable from your guitar to the Script Phase 90's Input jack and run another cable from the Script Phase 90's Output jack to your amplifier.
- Start with the SPEED knob at 12 o'clock.
- Turn the effect on by depressing the footswitch.
- Rotate the SPEED knob clockwise for a faster phase effect and counterclockwise for a slower phase effect.

SAMPLE SETTINGS

CLASSIC 80's ROCK

9:00



SPEED

PSEUDO LESLIE

12:00



SPEED

SPECIFICATIONS

Input Impedance	470 kΩ
Output Impedance	10 kΩ
Max Input Level	-5 dBV
Signal to Noise Ratio*	> 95 dB
Current Draw	8.2 mA
Bypass	True Hardwire
Power Supply	9 volts DC

** A-weighted, all controls at mid position*

